

TOE PLATES

INSTRUCTIONS



This is a fast way to check / set front end toe. It is affected by wheel or tire runout. Be certain wheels run true and tires have no bulges.

- Caster and Camber should be previously set.
- Ensure vehicle is on level ground.
- Turn wheels to straight ahead.
- Lean Toe Plates up against wheels. The folded lip faces outward. Be sure the entire plate is up against the wheel.
- Measure width and then the rear, using the slots for the tape measure.
- Subtract the smaller number from the larger. A larger front width indicates toe-out.

Longacre Racing Products
977 Hyrock Blvd.
Boonville, IN 47601

LongacreRacing.com

| 800-423-3110



LIT-5219 REV A

TOE PLATES

INSTRUCTIONS



This is a fast way to check / set front end toe. It is affected by wheel or tire runout. Be certain wheels run true and tires have no bulges.

- Caster and Camber should be previously set.
- Ensure vehicle is on level ground.
- Turn wheels to straight ahead.
- Lean Toe Plates up against wheels. The folded lip faces outward. Be sure the entire plate is up against the wheel.
- Measure width and then the rear, using the slots for the tape measure.
- Subtract the smaller number from the larger. A larger front width indicates toe-out.

Longacre Racing Products
977 Hyrock Blvd.
Boonville, IN 47601

LongacreRacing.com

| 800-423-3110



LIT-5219 REV A