




Longacre Racing Products, Inc.

Monroe, Wa. 360 453 2030
www.longacrerracing.com



- Switch down - mag grounded, motor off, light off
- Switch up - mag ungrounded, motor on, light on

If back of switch will get wet during use or washdown seal it with a good silicone sealer.

Switch problems are almost always caused by dirt carried in by water.