

SINGLE CHANNEL

INSTRUCTIONS



- Connect the digital display cable to the weigh pad. Turn the display on and allow it to warm up for 1 minute.
- Push zero if display is not on “0”. Capacity of system is 400 lbs unless marked otherwise.
- Display unit will operate on charger or battery (battery recommended). Low battery indicator is a flashing RED light. Connect charger. LED turns green (green LED does not go out when battery is charged). Charge time is 12 - 24 hours.

Keep this system clean and dry.

Do not drop pad or display.

Avoid electrostatic discharge.

Longacre Racing Products
977 Hyrock Blvd.
Boonville, IN 47601

LongacreRacing.com

| 800-423-3110



LIT-5183 REV A

SINGLE CHANNEL

INSTRUCTIONS



- Connect the digital display cable to the weigh pad. Turn the display on and allow it to warm up for 1 minute.
- Push zero if display is not on “0”. Capacity of system is 400 lbs unless marked otherwise.
- Display unit will operate on charger or battery (battery recommended). Low battery indicator is a flashing RED light. Connect charger. LED turns green (green LED does not go out when battery is charged). Charge time is 12 - 24 hours.

Keep this system clean and dry.

Do not drop pad or display.

Avoid electrostatic discharge.

Longacre Racing Products
977 Hyrock Blvd.
Boonville, IN 47601

LongacreRacing.com

| 800-423-3110



LIT-5183 REV A